



OKATEGORISERAD

EMERGENCY ALARM WC PACKAGE GB


Artikelnr: 03010002C

Alarm is activated by alarmbutton with label "EMERGENCY" on the roomunit or one of the wallmounted alarmbuttons. In case of alarm a indicator is activated outside the toilett with acustic and optical indication and a LED-indicator in the roomunit and alarmbuttons.

With the resetbutton on the roomunit with label "RESET" or by the external input for reset. Alarm can be forwarding by relay output in the roomunit. An instantaneous acoustic signal is available.

Ledtid

10 dagar



Driftspänning 12-24 VAC (\pm, %)	15
Driftspänning 12-24 VDC (\pm, %)	15
Ingång för signalkontakt	Slutande
Max strömförbrukning (mA)	218
Mått (Apparat, paketerad i kartong) (H*B*Dj, mm)	250x95x95
Reläutgång kontaktdata, Max spänning (V)	50
Reläutgång kontaktdata, Max ström (A)	1
Reläutgång potentialfri (1-pol)	Växlande
Vikt (Apparat, paketerad i kartong) (gram)	377



TJEDERS